




MECHATRONICS LABS SRL

IO-LINK SLAVE MODULE

EVALUATION BOARD

IOLx-E-EVK





Summary

1	INTRODUCTION	3
1.1	About this Manual	3
1.1.1	List of Revisions.....	3
1.1.2	Reference to Hardware.....	3
1.2	Other relevant documentation	3
2	DESCRIPTIONS AND DRAWINGS	4
2.1	Description of the IOLx-E-EVK	4
2.2	Drawings	5
2.2.1	Block Diagram	5
2.2.2	Board details.....	6
3	FUNCTIONALITY DESCRIPTION	8
3.1	Start-up configuration	8
3.2	IOLS-E Simple mode	10
3.3	IOLS-E Host Mode.....	12
3.4	Microcontroller	13
3.5	External interface connections.....	14
4	SCHEMATICS	17
5	ELECTRICAL CHARACTERISTICS	27
6	Order information	29
7	Legal Information	29
7.1	Definitions	29
7.2	Disclaimers.....	29
7.3	Trademarks.....	30
8	Contact information.....	30



1 INTRODUCTION

1.1 About this Manual

This manual describes the IOLx-E-EVK, the Evaluation Board of IOLx-E.

1.1.1 List of Revisions

Index	Date	Chapter	Revision
1.0	02-11-2017	All	Created
1.1	13-09-2018	All	Update to new hardware version. The functions of the board are same. Add some feature and change dimension of the board.

Table 1.1. List of revisions

1.1.2 Reference to Hardware

Hardware	Revision	Part Number
IOLS-E	2.0	IOLS-E-00S

Table 1.2. Reference to Hardware

1.2 Other relevant documentation

In addition to this document, the following documents are also relevant for the user of the IOLx-E-EVK Evaluation Board

Manual	Documentation name
Reference Manual of IOLS-E	DOC000001RM11EN.pdf

Table 1.3. Additional documentation



2 DESCRIPTIONS AND DRAWINGS

2.1 Description of the IOLx-E-EVK

The IOLx-E-EVK is the Evaluation Board of the component IOLS-E.

It is equipped with a IOLS-E-00S and following features:

- Power supply from different source: USB, IO-Link and direct 3,3V on interface connector.
- Switches for start-up configuration of the module IOLS-E
- Use in simple mode with shift register Input and Output and two analog input on board. On evaluation there are 16 switches IN and 16 LEDs OUT, and potentiometer and temperature analog sensors.
- Use in host mode with external microcontroller interfaced to module IOLS-E. On board there is a STM32F0 family microcontroller with 4 INPUTS and 4 OUTPUTS and 2 ANALOG, already interfaced to microcontroller. Is available the demo application that uses toolkit for communication with module.
- ST microcontroller is programmable with JTAG SWD standard connector. Use this for implement your demo application. There are some pin of microcontroller to external interface connector with GPIO, UART, I2C and ANALOG functions.
- USB connector for communication with external application, that communicates with module for configuration and firmware update.
- SPI interface of the module IOLS-E is available to external interface connector for free use. The start-up configuration determines if the module is used in simple or host mode.
- First byte of the input and output shift registers is available to external interface connector
- The 4 inputs and 4 outputs and 2 analogs on ST microcontroller are available to external connector, and they already read and write from demo application.



2.2 Drawings

2.2.1 Block Diagram




Figure 2.1 . Diagram block

2.2.2 Board details




Figure 2.2 . Board details



Details number	Description
1	IO-Link Slave Module IOLS-E
2	Simple mode - Shift register Data Input (16 bits)
3	Simple mode - Shift register Data Output (16 bits)
4	Host mode – microcontroller STM32F0 and in/out
5	Jumper for switch selection between simple and host mode
6	IO-Link M12 connector class A port (3 wire)
7	LEDs for IO-Link bus communication status
8	Start-up switch configuration of the module IOLS-E
9	Analog unit – Potentiometer
10	Analog unit – Temperature sensor
11	USB connector – power and communication
12	External interface connector when module is into simple mode configuration
13	External interface connector when module is into host mode configuration
14	External interface connector for direct communication with module. There is SPI interface of the module IOLS-E. Master or slave setting is function of start-up configuration.
15	Push-button for reset and boot selection of the module IOLS-E and ST microcontroller.

Table 2.1. Board details



3 FUNCTIONALITY DESCRIPTION

3.1 Start-up configuration

The IOLS-E module can work either in Simple mode or in Host mode. Refer to reference manual of the component.

Selection is done by SW4 according to Table 3.1.



Configuration HW Pin				Module Configuration mode	Configuration parameters	Data image Slave to/from Master IO-Link										
Pin CFGSSIO	Pin CFG2	Pin CFG1	Pin CFG0			B00	B01	B02	B03	B04	B..	B07	B..	B11	B..	B31
0	0	0	0	SIMPLE MODE Autonomous functionality with SSIO (Shift register) and ANALOG channel	4byte ANA; 4byte SSIO (8 PDIN, 4 PDOUT)	AN0	AN0	AN1	AN1	SR0	SR..	SR3	X	X	X	X
0	0	0	1		4byte ANA; 8byte SSIO (12 PDIN, 8 PDOUT)	AN0	AN0	AN1	AN1	SR0	SR..	SR3	SR..	SR7	X	X
0	0	1	0		4byte ANA; 28byte SSIO (32 PDIN, 28 PDOUT)	AN0	AN0	AN1	AN1	SR0	SR..	SR3	SR..	SR7	SR..	SR27
0	0	1	1		4byte SSIO (4 PDIN, 4 PDOUT)	SR0	SR1	SR2	SR3	X	X	X	X	X	X	X
0	1	0	0		8byte SSIO (8 PDIN, 8 PDOUT)	SR0	SR1	SR2	SR3	SR4	SR..	SR7	X	X	X	X
0	1	0	1		32byte SSIO (32 PDIN, 32 PDOUT)	SR0	SR1	SR2	SR3	SR4	SR..	SR7	SR..	SR11	SR..	SR31
0	1	1	0		Reserved for use future	Undefined										
0	1	1	1		Reserved for use future	Undefined										
1	0	0	0		HOST MODE Need external host. Module communication IO-Link protocol feature only	Use Serial Modbus host interface*	Host depend - Cyclic Data Exchange registers									
1	0	0	1	Use SPI register access host interface		Host depend - Cyclic Data Exchange registers										
1	0	1	0	Reserved for use future		Undefined										
1	0	1	1			Undefined										
1	1	0	0			Undefined										
1	1	0	1			Undefined										
1	1	1	0			Undefined										
1	1	1	1	Undefined												

NOTE: 1 = pull-up resistor; 0 = not mount
* Modbus RTU interface is ever enabled.

Table 3.1. Start-up function IOLS-E configuration

3.2 IOLS-E Simple mode

In Simple mode the SSIO port is used and internal ADC can be enabled.

The IOLS-E can exchange data on SSIO port either with shift registers mounted on the evaluation board and with an external shift register device connected to the SSIO headers up to J4 on J4.2, J4.4, J4.19, J4.21, J4.22 .

Shift registers are then connected to switches SW1, SW2 and to LEDs D1 to D16. Refer to section SCHEMATICS.

If the selection headers J10 to J15 are closed with jumpers, like in Figure 3.1, IOLS-E works in Simple mode and it reads the status of the switches SW1 and SW2 that represent 16-bit input data and set drives the LEDs D1 to D16 writing 16-bit data on the output. The switch 8 of SW2 is the input LSB and the switch 1 of SW1 is the input MSB. D1 and D16 represent the output LSB and MSB respectively.

J4 can be used to connect an external device in alternative to SW1 and LEDs D9 to D16 to exchange 8-bit data. Refer to Table 3.2 for J4 signals.




Figure 3.1. Selection headers J10 to 15 Simple Mode

SIGNAL	TYPE	FUNCTION
3V3	POWER	It can provide either 3.1V as output or receive 3.3V (3.6V MAX) from an external source
CLK	OUTPUT	Clock signal (from IOLS-E to external device)
Q0 to Q7	OUTPUT	8-bit parallel data output. Outputs and LEDs D9 to D16 are driven simultaneously
SDI	INPUT	IOLS-E serial data input for shift register
D0 to D7	INPUT	8-bit parallel data input. To avoid conflict with SW2 put all SW2 switches in OFF position
SDO	OUTPUT	IOLS-E serial data output for shift register
LI	OUTPUT	Latch-In signal (from IOLS-E to external device)
LO	OUTPUT	Latch-Out signal (from IOLS-E to external device)
GND	GROUND	Signal ground

Table 3.2. J4 pin signals Simple mode



If the IOLS-E internal ADC is enabled, the module can read the signal of the temperature sensor (U6) and the voltage value from the potentiometer (R20).

The temperature sensor output is proportional to the temperature according the following equation:

$$V_{OUT} = 20\text{mV} * T + 1\text{V} \quad \text{Where: } -40^{\circ}\text{C} \leq T \leq 115^{\circ}\text{C}.$$

The potentiometer output can swing from 0V to 3V3 level.

The 3V3 level is also the ADC full-scale value.

Two auxiliary analog inputs are also available on J5 (AN0 and AN1) that can be chosen as alternative to the sensor and the potentiometer. Selection is made by headers J6 and J7 (see Figure 3.2 and Figure 3.3). They are connected direct to input ADC pin signals.




Figure 3.2. Sensor and pot. Selected J6..J7



Figure 3.3. Auxiliary external analog inputs selected J6..J7

SIGNAL	TYPE	FUNCTION
3V3	POWER	It can provide either 3.1V as output or receive 3.3V (3.6V MAX) from an external source
AN0	INPUT	Analog 0 external input
AN1	INPUT	Analog 1 external input
POT	INPUT	Analog potentiometer signal
TEMP	INPUT	Analog temperature signal
DAC	OUTPUT	Digital Analog output (Reserved for future)
GND	GROUND	Signal ground

Table 3.3. J5 pin for external analog inputs

3.3 IOLS-E Host Mode

When the IOLS-E module works in Host mode, it can exchange data on SPI and USB ports. The module internal ADC is always disabled. Module works only for support IO-Link communication. The application runs into host.

If the SPI port is enabled (see Table 3.1) the IOLS-E module can exchange data either with the ST microcontroller mounted on the evaluation board or with external devices connected to the middle pin on the headers J10 to J15 (see Chapter 3.5).

If the selection headers J10 to J15 are closed with jumpers, like in Figure 3.4, the IOLS-E exchanges data with the microcontroller mounted on the evaluation board.




Figure 3.4. Selection headers J10..15 Host Mode



3.4 Microcontroller

The microcontroller is STM32F030C8T6 and has four analog inputs:

- temperature sensor
- potentiometer
- two auxiliary analog inputs on connector J8

It can read the status of the switch SW4 and can drive four LEDs: D21 to D24. The demo application reads and exchanges with IOLS-E module all 4 analog inputs and all 8 digital input and output, on board and external interface on J8 connector. More, on J8 are available Serial interface UART and some pin GPIOs have also other functionality, like I2C bus.

The microcontroller can exchange data with a device connected to J8. Refer to Table 3.4 for J8 signals.

SIGNAL	TYPE	FUNCTION
3V3	POWER	It can provide either 3.1V as output or receive 3.3V (3.6V MAX) from an external source
D0 to D3	OUTPUT	4-bit parallel data input
Q0 to Q3	INPUT	4-bit parallel data output; Q3 and Q2 can be configured to SDA and SCL I2C bus signals.
TX	OUTPUT	UART TX (TTL LEVEL)
RX	INPUT	UART RX (TTL LEVEL)
SCL	OUT	I2C Clock Signal
SDA	BIDIR	I2C Data Signal
AN2	INPUT	Analog auxiliary input. The 3V3 level is the ADC full-scale value. Direct to ADC pin signal.
AN3	INPUT	Analog auxiliary input. The 3V3 level is the ADC full-scale value. Direct to ADC pin signal.
GND	GROUND	Signal ground

Table 3.4. J8 pin signals

The microcontroller is already programmed, user can anyway write its own firmware on it using the serial wire interface available on J24:

SIGNAL	TYPE	FUNCTION
3V3	OUTPUT	I/O voltage level
CLK	INPUT	SWCLK signal
GND	GROUND	Signal ground
DIO	BIDIR	SWDIO signal
RST	INPUT	Reset signal
NC	---	Not connected

Table 3.5. J24 pin signals

3.5 External interface connections

If the selection headers J10 to J15 are left open, IOLS-E exchanges data with an external device connected to the middle pin of J10 to J15, refer to Figure 3.5 and Table 3.7 for signals. IOLS-E can work either in Simple mode and in Host mode while connected with an external device. **Remember:** You must to connect to any other ground signal on the board while using the J10 to J15 headers.




Figure 3.5. Selection headers J10 to 15 External mode

SIGNAL	TYPE	FUNCTION
J10.CLK	OUTPUT	Clock signal (from IOLS-E to external device)
J11.MIS	INPUT	IOLS-E serial data input
J12.MOS	OUTPUT	IOLS-E serial data output
J13.LO/CS	OUTPUT	Latch-Out signal (from IOLS-E to external device)
J14.LI/D	OUTPUT	Latch-In signal (from IOLS-E to external device)
J15.RST	NOT CONNECTED	

Table 3.7. J10 to 15 middle pin signals External mode

IOLINK Slave Module

Technical Datasheet IOLx-E-EVK

Revision 1.1

Document No.: DOC000002DS11EN



Mechatronics Labs
YOUR ASPIRATION, OUR INSPIRATION.

The IOLx-E-EVK board can also be cut in three pieces if the microprocessor and the input sections are not needed, leaving the IO-Link Slave Module detached as shown in Figure 3.6. The remaining Slave Module can be connected with an external device by using J25 and J26 headers. Refer to Table 3.8, 3.9 for J25 and J26 signals.

If you want, you can divide board in only two parts, in this mode you can to use a connector M12 and USB interface, for IO-Link connection and for firmware update from USB.




Figure 3.6. cut the board on the following lines

SIGNAL	PIN	TYPE	FUNCTION
3V3	1	POWER	Logic 3.3V Voltage. If IO-Link is connected 3.3V is supply from module. Is possible that you have external supply if desired.
N.C.	2	-	
VP	3	POWER	IO-Link Vplus
CQ	4	BI-DIRECTIONAL	IO-Link C/Q signal
VM	5	POWER	IO-Link Ground
N.C.	6	-	
TX	7	OUTPUT	UART Serial transmit data
RX	8	INPUT	UART Serial receive data
RSVD	9	-	
RSVD	10	-	
RSVD	11	-	
GND	12	POWER	Ground signal

Table 3.8. J25 pin signals

SIGNAL	PIN	TYPE	FUNCTION
--------	-----	------	----------

IOLINK Slave Module

Technical Datasheet IOLx-E-EVK

Revision 1.1

Document No.: DOC000002DS11EN



MechatronicsLabs
YOUR ASPIRATION, OUR INSPIRATION.

3V3	1	POWER	Logic 3.3V Voltage. If IO-Link is connected 3.3V is supply from module. Is possible that you have external supply if desired.
CLK	2	OUTPUT or INPUT	Clock generation or clock signal input. Is function of the start-up configuration – If Simple mode SPI is master, if Host mode SPI is slave.
MISO	3	OUTPUT or INPUT	SPI Master input or Slave output. Is function of the start-up configuration – If Simple mode SPI is master, if Host mode SPI is slave.
MOSI	4	OUTPUT or INPUT	SPI Master output or Slave input. Is function of the start-up configuration – If Simple mode SPI is master, if Host mode SPI is slave.
LI/D	5	OUTPUT or INPUT	Latch IN or DIRQ - Is function of the start-up configuration – If Simple mode is Latch IN for shift registers, if Host mode is a Data Interrupt Request (DIRQ not yet implement).
LO/CS	6	OUTPUT or INPUT	Latch OUT or Slave Select/Chip Select. Is function of the start-up configuration – If Simple mode is Latch OUT for shift registers, if Host mode is a SPI Slave Select.
RST	7	OUTPUT	Module reset signal. Reset is Low.
BOOT	8	INPUT	Module boot signal – When reset with this pin Low, you start internal boot for firmware update.
AN0	9	INPUT	Analog 0 input. Range 0 - 3.3V.
AN1	10	INPUT	Analog 1 input. Range 0 - 3.3V.
DAC	11	INPUT	Analog Output. Range 0 - 3.3V. (Not yet implement)
GND	12	POWER	Ground signal

Table 3.9. J26 pin signals



4 SCHEMATICS

The follow pages, view schematic of the evaluation board, and report Bill of Material.

IO-LINK Slave Module


Technical Datasheet IOLx-E-EVK

Revision 1.1

Document No.: DOC000002DS11EN



Mechatronics Labs
YOUR ASPIRATION, OUR INSPIRATION.



IO-LINK Slave Module


Technical Datasheet IOLx-E-EVK

Revision 1.1

Document No.: DOC000002DS11EN




Mechatronics Labs
YOUR ASPIRATION, OUR INSPIRATION.




SW4
IO-Link Module
CONFIG Switches

0 = open
1 = closed


1	2	3	4	FUNCTION
0	x	x	x	SIMPLE MODE
0	0	0	0	SSIO 4BYTE IN, 4BYTE OUT, ADC Enabled
0	0	0	1	SSIO 4BYTE IN, 8BYTE OUT, ADC Enabled
0	0	1	0	SSIO 4BYTE IN, 32BYTE OUT, ADC Enabled
0	0	1	1	SSIO 0BYTE IN, 4BYTE OUT, ADC Disabled
0	1	0	0	SSIO 0BYTE IN, 8BYTE OUT, ADC Disabled
0	1	0	1	SSIO 0BYTE IN, 32BYTE OUT, ADC Disabled
0	1	1	0	---
0	1	1	1	---
1	x	x	x	HOST MODE
1	0	0	0	SPI Disabled, MODBUS Enabled, ADC Disabled
1	0	0	1	SPI Enabled, MODBUS Disabled, ADC Disabled
1	0	1	0	SPI Enabled, MODBUS Enabled, ADC Disabled
1	0	1	1	---
1	1	0	0	---
1	1	0	1	---
1	1	1	0	---
1	1	1	1	---



		Mechatronics Labs S.r.l. via Ormago, 24 20882 Bellusco (MB) Italy			
		Title design SC16008EVKxx - IO-Link Evaluation Kit <Variant Name>			
Des. Villa R.	Tuesday, November 14, 2017	Size A3	Cod SC16008EVK11	Document Number <Doc>	Ver 1.1
Appd. Zalferi P.	Friday, February 09, 2018	Title Sheet IO-LINK		Sheet 4 of 9	



		Mechatronics Labs S.r.l. via Ormago, 24 20882 Bellusco (MB) Italy		
Des. Villa R.		Title design SC16008EVKxx - IO-Link Evaluation Kit <Variant Name>		
Appd. Zallieri P.		Tuesday, November 14, 2017	Size A3	Cod SC16008EVK11
Friday, February 09, 2018		Document Number <Doc>		Ver 1.1
Title Sheet SHIFT REGISTERS		Sheet 5 of 9		



		Mechatronics Labs S.r.l. via Ormago, 24 20882 Bellusco (MB) Italy			
		Title design SC16008EVKcx - IO-Link Evaluation Kit <Variant Name>			
Des. Villa R.	Tuesday, November 14, 2017	Size A3	Cod SC16008EVK11	Document Number <Doc>	Ver 1.1
Appd. Zaltoni P.	Friday, February 09, 2018	Title Sheet ANALOG SOURCES		Sheet 6 of 9	

IOLINK Slave Module


Technical Datasheet IOLx-E-EVK

Revision 1.1


Document No.: DOC000002DS11EN



Mechatronics Labs
YOUR ASPIRATION, OUR INSPIRATION.



		Mechatronics Labs S.r.l. via Ormago, 24 20882 Bellusco (MB) Italy		
Title design SC16008EVKxx - IO-Link Evaluation Kit <Variant Name>				
Des. Villa R.	Tuesday, November 14, 2017	Size A3	Cod SC16008EVK11	Document Number <Doc>
Appd. Zalieri P.	Friday, February 09, 2018	Title Sheet MICRO		Ver 1.1
		Sheet 7 of 9		



		Mechatronics Labs S.r.l. via Ormago, 24 20882 Bellusco (MB) Italy	
Title design SC16008EVKxx - IO-Link Evaluation Kit <Variant Name>			
Des. Villa R.	Tuesday, November 14, 2017	Size A3	Cod SC16008EVK11
Appd. Zaltoni P.	Friday, February 09, 2018	Document Number <Doc>	Ver 1.1
Title Sheet SILKSCREEN		Sheet 9 of 9	



Item Number	Quantity	Part Reference	Value	Description	Vendor_PN
1	12	C1 C2 C6 C8 C13 C15 C16 C17 C18 C23 C24 C27	100nF	SMT CAP 100nF, 50V, 0402, X7R, ±10%	GCM155R71H104KE0 2D
2	3	C4 C14 C22	4.7uF	SMT CAP 4.7uF, 10V, 0402, X5R, ±20%	0402ZD475MAT2A
3	2	C7 C19	1uF	SMT CAP 1uF, 16V, 0402, X5R, ±10%	C0402C105K4PACTU
4	5	C9 C10 C11 C12 C28	3.3nF	SMT CAP 3.3nF, 50V, 0402, X7R, ±10%	C0402C332K5RACTU
5	1	C20	10nF	SMT CAP 10nF, 50V, 0402, X7R, ±10%	C0402C103K5RACTU
6	2	C25 C26	22uF	SMT CAP 22uF, 6.3V, 0603, COG, ±20%	GRM188C60J226MEA 0D
7	1	CS1	SC16008EVK11	PRINTED CIRCUIT BOARD SC16008EVK11, 4 LAYERS	
8	22	D1 D2 D3 D4 D5 D6 D7 D8 D9 D10 D11 D12 D13 D14 D15 D16 D18 D21 D22 D23 D24 D26	APT1608SGC	LED 120°, Green	APT1608SGC
9	1	D17	APT1608EC	LED 120°, Red	APT1608EC
10	3	D19 D25 D27	SD1206T040S2 R0	DIODE SCHOTTKY Rectifier, 40V, 2A	SD1206T040S2R0
11	1	J1	1411984	CONN M12, SMT, Male, Type A, Pin 5	1411984
12	1	J3	105133-0001	CONN MICRO USB, SMT, FEMALE, Receptacle, Type B, Vertical, Pin 5	105133-0001
13	1	J4	M20-9761246	CONN HEADER, THT, MALE, 2 ROW, Pitch 2.54mm, Pin 2x12	M20-9761246
14	1	J5	M20-9760346	CONN HEADER, THT, MALE, 2 ROW, Pitch 2.54mm, Pin 2x3	M20-9760346
15	8	J6 J7 J10 J11 J12 J13 J14 J15	M20-9770346	CONN HEADER, THT, MALE, 1 ROW, Pitch 2.54mm, Pin 3	M20-9770346
16	1	J8	M20-9760846	CONN HEADER, THT, MALE, 2 ROW, Pitch 2.54mm, Pin 2x8	M20-9760846
17	8	J16 J17 J18 J19 J20 J21 J22 J23	60900213421	CONN JUMPER, THT, Jumper with Test Point WR-PHD, Pitch 2.54mm, Pin 2	60900213421
18	1	J24	M20-9770646	CONN HEADER, THT, MALE, 1 ROW, Pitch 2.54mm, Pin 6	M20-9770646
19	1	Q1	BC847BPDW1	TRANSISTOR, PNP-NPN, PNP + NPN, 45V, 100mA, 380mW	BC847BPDW1T3G
20	2	R2 R7	3K3	RES 3K3, 0402, ±1%, 50V, 1/16W	CRCW04023K30FKED



21	2	R3 R4	220R	RES 220R, 0402, ±1%, 50V, 1/16W	CRCW0402220RFKED
22	6	R15 R18 R19 R21 R27 R39	470R	RES 470R, 0402, ±1%, 50V, 1/16W	CRCW0402470RFKED
23	11	R16 R17 R22 R28 R32 R33 R34 R35 R37 R38 R40	10K	RES 10K, 0402, ±1%, 50V, 1/16W	CRCW040210K0FKED
24	1	R20	10K	RES 10K, TRIMMER THT, ±25%, 20V, 20mW	3319P-1-103
25	3	R24 R25 R26	22R	RES 22R, 0402, ±1%, 50V, 1/16W	CRCW040222R0FKED
26	1	R36	100R	RES 100R, 0402, ±1%, 50V, 1/16W	CRCW0402100RFKED
27	6	RN1 RN5 RN6 RN11 RN12 RN23	3K3	RES 3K3, CAY16, ±5%, 50V, 1/16W	CAY16-332J4LF
28	5	RN8 RN9 RN13 RN14 RN29	390R	RES 390R, CAY16, ±5%, 50V, 1/16W	CAY16-391J4LF
29	2	SW1 SW2	ADE08S04	SWITCH DIP SWITCH SMT, Extended Actuator, Pin 8, 2.54mm	ADE08S04
30	1	SW3	ADE04S04	SWITCH DIP SWITCH SMT, Extended Actuator, Pin 4, 2.54mm	ADE04S04
31	1	SW4	97C04ST	SWITCH DIP SWITCH SMT, Low Profile, Half-pitch, Pin 4, 1.27mm	97C04ST
32	4	SW5 SW6 SW7 SW8	LL3301NF065Q G	SWITCH PUSH BUTTON SMT, Pin 4	LL3301NF065QG
33	1	U1	MLIO11	IC IO-Link Slave Controller	IOLS-E
34	2	U2 U4	74HC595BQ	IC 8bit serial-in, serial/parallel-out SHIFT REGISTER, tri-state output, Package: DHVQFN16	74HC595BQ,115
35	2	U3 U5	74HC165BQ	IC 8bit parallel-in, serial-out SHIFT REGISTER, Package: DHVQFN16	74HC165BQ,115
36	1	U6	MCP9700T- E/TT	IC Low-power Linear Active Thermistor (10mV*°C, +/-2°C)	MCP9700T-E/TT
37	1	U8	STM32F030C8T 6	IC Entry-level ARM Cortex-M0 Value line MCU with 64 Kbytes Flash, 48 MHz CPU	STM32F030C8T6
38	1	U9	FT232RQ	IC USB to serial UART interface QFN32	FT232RQ
39	1	U10	OPA348AIDBVR	IC Rail-to-Rail OPA, Single Supply +2.1V to 5.5V	OPA348AIDBVR
40	1	U7	OPA2348AIDR	IC Rail-to-Rail OPA, Single Supply +2.1V to 5.5V	OPA2348AIDR

Table 4.1. Bill of Material



5 ELECTRICAL CHARACTERISTICS

The Evaluation Board can be powered in three ways:

- Connecting an IO-Link Master to J1 or J2
- Providing 5V on the USB connector
- Providing 3.3V on 3V3 pins of J4, J5, J8 connectors

If the Evaluation Board is powered either by IO-Link Bus or by USB connector, the Board can provide 3.1V (typically) on 3V3 pins of J4, J5, J8 connectors using its internal LDOs.

The Evaluation Board can be supplied also applying a voltage greater than 3.1V on 3V3 pins of J4, J5, J8 connectors. In this way the internal LDOs are inhibited.

PARAMETER	DESCRIPTION	CONDITION	Min	MAX	UNIT
IO-Link VPLUS (V+)			-40	+40	V
IO-Link CQ			-40	+40	V
USB Vcc			-0.5	+6	V
USB DP & DM			-0.5	+3.8	V
3V3 (Vin)		No power supply applied neither to IO-Link Bus nor to USB connector	-0.3	4	V
I/O Vin	Input voltage on any digital or analog pin		-0.3	4	V
I/O Iout	Output current source by any digital pin			25	mA

Table 5.1. Absolute maximum ratings

IOLINK Slave Module

Technical Datasheet IOLx-E-EVK

Revision 1.1

Document No.: DOC000002DS11EN



Mechatronics Labs
YOUR ASPIRATION, OUR INSPIRATION.

PARAMETER	DESCRIPTION	CONDITION	Min	Typ.	MAX	UNIT
IO-Link VPLUS (V+)	Operating supply Voltage		5	24	30	V
IO-Link Icc	Operating supply Current	No power supply applied to USB connector, No devices connected to J4, J5, J8		2		mA
IO-Link CQ			-10		VPLUS + 10	V
USB Vcc	Operating supply Voltage		4		5.25	V
USB Icc	Operating supply Current	No power supply applied to IO-Link Bus, No devices connected to J4, J5, J8		25		mA
USB Voh	Output (High)		2.8		3.6	
USB Vol	Output (Low)		0		0.3	V
USB Vse	Single ended Rx Threshold		0.8		2.0	V
USB Com	Differential common Mode		0.8		2.5	V
USB Vdif	Differential input Sensitivity		0.2			V
USB DrvZ	Driver output Impedance		26	29	44	Ω
3V3 Vout	LDOs output Voltage	Supplied either by IO-Link bus or by USB	2.8	3.1	3.4	V
3V3 Iout	LDOs output Capability	Supplied either by IO-Link bus or by USB	50			mA

Table 5.2. Normal Operating conditions



6 Order information

Type number	Package style	Package MOQ
IOLx-E-EVK	Box	1

Table 6.1. Order information

7 Legal Information

It is prohibited from distribution and reproduction, even partial, of this document without written permission of the Mechatronics Labs srl.

Mechatronics Labs srl will not accept any partial or total claim caused due to use or the failure of this product.

Mechatronics Labs srl cannot provide any guarantee on performance and results obtained from the use of this documentation and product, and cannot be held liable for damages or benefits arising from the misuse of this documentation and the products to which it relates.

The same applies to any person or company involved in the creation, production and distribution of this document. This document provides preliminary information that may be subject to change without notice.

7.1 Definitions

Draft — The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. Mechatronics Labs does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

Short data sheet — A short data sheet is an extract from a full data sheet with the same product type number(s) and title. A short data sheet is intended

for quick reference only and should not be relied upon to contain detailed and full information. For detailed and full information is available on request via the local Mechatronics Labs sales office. In case of any inconsistency or conflict with the short data sheet, the full data sheet shall prevail.

Product specification — The information and data provided in a Product data sheet shall define the specification of the product as agreed between Mechatronics Labs and its customer, unless Mechatronics Labs and customer have explicitly agreed otherwise in writing. In no event however, shall an agreement be valid in which the Mechatronics Labs product is deemed to offer functions and qualities beyond those described in the Product data sheet.

7.2 Disclaimers

Limited warranty and liability — Information in this document is believed to be accurate and reliable. However, Mechatronics Labs does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. Mechatronics Labs takes no responsibility for the content in this document if provided by an information source outside of Mechatronics Labs. In no event shall Mechatronics Labs be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory. Notwithstanding any damages that customer might incur for any reason whatsoever, Mechatronics Labs' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the *Terms and conditions of commercial sale* of Mechatronics Labs.

Right to make changes — Mechatronics Labs reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — Mechatronics Labs products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an Mechatronics Labs product can reasonably be expected to result in personal injury, death or severe property or environmental damage. Mechatronics Labs and its suppliers accept no liability for inclusion and/or use of Mechatronics Labs products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Applications — Applications that are described herein for any of these products are for illustrative purposes only. Mechatronics Labs makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification. Customers are responsible for the design and operation of their applications and products using Mechatronics Labs products, and Mechatronics Labs accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the Mechatronics Labs product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products. Mechatronics Labs does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using Mechatronics Labs products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). Mechatronics Labs does not accept any liability in this respect.

IOLINK Slave Module

Technical Datasheet IOLx-E-EVK

Revision 1.1

Document No.: DOC000002DS11EN



Mechatronics Labs
YOUR ASPIRATION, OUR INSPIRATION.

Limiting values — Stress above one or more limiting values (as defined in the Absolute Maximum Ratings System of IEC 60134) will cause permanent damage to the device. Limiting values are stress ratings only and (proper) operation of the device at these or any other conditions above those given in the Recommended operating conditions section (if present) or the Characteristics sections of this document is not warranted. Constant or repeated exposure to limiting values will permanently and irreversibly affect the quality and reliability of the device.

Terms and conditions of commercial sale — Mechatronics Labs products are sold subject to the general terms and conditions of commercial sale, unless otherwise agreed in a valid written individual agreement. In case an individual agreement is concluded only the terms and conditions of the respective agreement shall apply. Mechatronics Labs hereby expressly objects to applying the customer's general terms and conditions with regard to the purchase of Mechatronics Labs products by customer.

No offer to sell or license — Nothing in this document may be interpreted or construed as an offer to sell products that is open for acceptance or the grant, conveyance or implication of any license under any copyrights, patents or other industrial or intellectual property rights.

Export control — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

Non-automotive qualified products — Unless this data sheet expressly states that this specific Mechatronics Labs product is automotive qualified, the product is not suitable for automotive use. It is neither qualified nor tested in accordance with automotive testing or application requirements. Mechatronics Labs accepts no liability for inclusion and/or use of non-automotive qualified products in automotive equipment or applications.

In the event that customer uses the product for design-in and use in automotive applications to automotive specifications and standards, customer (a) shall use the product without Mechatronics Labs' warranty of the product for such automotive applications, use and specifications, and (b) whenever customer uses the product for automotive applications beyond Mechatronics Labs' specifications such use shall be solely at customer's own risk, and (c) customer fully indemnifies Mechatronics Labs for any liability, damages or failed product claims resulting from customer design and

use of the product for automotive applications beyond Mechatronics Labs' standard warranty and Mechatronics Labs' product specifications.

7.3 Trademarks

Notice: All referenced brands, product names, service names and trademarks are the property of their respective owners.

8 Contact information

For more information, please visit <http://www.mechatronicslabs.it>

For sales office addresses, please send an email to: info@mechatronicslabs.it